

Universal Windows Platform 编程学习笔记

Roger Young

2017 年 9 月 18 日

目录

目录	3
第一章 Get started with the Universal Windows Platform	5
1.1 What's a Universal Windows Platform (UWP) app?	5
1.1.1 So, what exactly is a UWP app?	5
1.1.2 Use a language you already know	6
1.1.3 UWP apps come to life on Windows	6
1.1.4 Monetize your app	7
1.1.5 Let's get started	7
第二章 了解应用程序项目	9
第三章 XAML 界面原理和语法	11
第四章 应用导航	13
第五章 页面排版	15
第六章 控件	17
第七章 数据视图	19
第八章 图形	21
第九章 动画	23
第十章 图像	25
第十一章 多媒体	27
第十二章 启动与激活	29
第十三章 文件和数据	31
13.1 文件与目录	31
13.2 XML 数据处理	31

13.2.1 XML 格式简介	31
13.2.2 读写 XML	31
13.2.3 相关类简介	33
13.3 JSON 数据处理	33
第十四章 应用设置和数据	35
第十五章 数据库编程	37
15.1 SQLite 数据库的使用	37
15.1.1 C# Example	37
15.1.2 SQLite C# API Wrappers	38
15.1.3 Visual Studio set-up	38
15.1.4 Code	39
15.1.5 What about Entity Framework?	43
15.1.6 Conclusion	44
第十六章 网络通信	45
第十七章 传感器与地理信息	47
第十八章 语言识别技术	49
18.1 元素周期表	51
18.2 密码子表	

第一章 Get started with the Universal Windows Platform

1.1 What's a Universal Windows Platform (UWP) app?

The Universal Windows Platform (UWP) is the app platform for Windows 10. You can develop apps for UWP with just one API set, one app package, and one store to reach all Windows 10 devices – PC, tablet, phone, Xbox, HoloLens, Surface Hub and more. It's easier to support a number of screen sizes, and also a variety of interaction models, whether it be touch, mouse and keyboard, a game controller, or a pen. At the core of UWP apps is the idea that users want their experiences to be mobile across ALL their devices, and they want to use whatever device is most convenient or productive for the task at hand.

UWP is also flexible: you don't have to use C# and XAML if you don't want to. Do you like developing in Unity or MonoGame? Prefer JavaScript? Not a problem, use them all you want. Have a C++ desktop app that you want to extend with UWP features and sell in the store? That's okay, too.

The bottom line: You can spend your time working with familiar programming languages, frameworks and APIs, all in single project, and have the very same code run on the huge range of Windows hardware that exists today. Once you've written your UWP app, you can then publish it to the store for the world to see.

1.1.1 So, what exactly is a UWP app?

What makes a UWP app special? Here are some of the characteristics that make UWP apps on Windows 10 different.

- There's a common API surface across all devices.

The Universal Windows Platform (UWP) core APIs are the same for all classes of Windows device. If your app uses only the core APIs, it will run on any Windows 10 device, no matter if you are targeting a desktop PC, an Xbox or a Mixed Reality headset.

- Extension SDKs let your app do cool stuff on specific device types.

Extension SDKs add specialized APIs for each device class. For example, if your UWP app targets HoloLens, you can add HoloLens features in addition to the normal UWP core APIs. If

you target the universal APIs, your app package can run on all devices that run Windows 10. But if you want your UWP app to take advantage of device specific APIs in the event it is running on a particular class of device, you can check at run-time if an API exists before calling it.

- Apps are packaged using the .AppX packaging format and distributed from the Store.

All UWP apps are distributed as an AppX package. This provides a trustworthy installation mechanism and ensures that your apps can be deployed and updated seamlessly.

- There's one store for all devices.

After you register as an app developer, you can submit your app to the store and make it available on all types device, or only those you choose. You submit and manage all your apps for Windows devices in one place.

- Apps support adaptive controls and input

UI elements use effective pixels (see Responsive design 101 for UWP apps), so they can respond with a layout that works based on the number of screen pixels available on the device. And they work well with multiple types of input such as keyboard, mouse, touch, pen, and Xbox One controllers. If you need to further tailor your UI to a specific screen size or device, new layout panels and tooling help you adapt your UI to the devices your app may run on.

1.1.2 Use a language you already know

UWP apps use the Windows Runtime, a native API built into the operating system. This API is implemented in C++ and supported in C#, Visual Basic, C++, and JavaScript. Some options for writing apps in UWP include:

- XAML UI and a C#, VB, or C++ backend
- DirectX UI and a C++ backend
- JavaScript and HTML

Microsoft Visual Studio 2017 provides a UWP app template for each language that lets you create a single project for all devices. When your work is finished, you can produce an app package and submit it to the Windows Store from within Visual Studio to get your app out to customers on any Windows 10 device.

1.1.3 UWP apps come to life on Windows

On Windows, your app can deliver relevant, real-time info to your users and keep them coming back for more. In the modern app economy, your app has to be engaging to stay at the front of your users' lives. Windows provides you with lots of resources to help keep your users returning to your app:

- Live tiles and the lock screen show contextually relevant and timely info at a glance.
- Push notifications bring real-time, breaking alerts to your user's attention when they're needed.
- The Action Center is a place where you can organize and display notifications and content that users need to take action on.
- Background execution and triggers bring your app to life just when the user needs it.
- Your app can use voice and Bluetooth LE devices to help users interact with the world around them.
- Support for rich, digital ink and the innovative Dial.
- Cortana adds personality to your software.
- XAML provides you with the tools to create smooth, animated user interfaces.

Finally, you can use roaming data and the Windows Credential Locker to enable a consistent roaming experience across all of the Windows screens where users run your app. Roaming data gives you an easy way to store a user's preferences and settings in the cloud, without having to build your own sync infrastructure. And you can store user credentials in the Credential Locker, where security and reliability are the top priority.

1.1.4 Monetize your app

On Windows, you can choose how you'll monetize your app—across phones, tablets, PCs, and other devices. We give you a number of ways to make money with your app and the services it delivers. All you need to do is choose the one that works best for you:

- A paid download is the simplest option. Just name your price.
- Trials let users try your app before buying it, providing easier discoverability and
- conversion than the more traditional "freemium" options.
- Use sale prices for apps and add-ons.
- In-app purchases and ads are also available.

1.1.5 Let's get started

For a more detailed look at the UWP, read the Guide to Universal Windows Platform apps. Then, check out Get set up to download the tools you need to start creating apps, and then write your first app!

第二章 了解应用程序项目

第三章 XMAL 界面原理和语法

第四章 应用导航

第五章 页面排版

第六章 控件

第七章 数据视图

第八章 图形

第九章 动画

第十章 图像

第十一章 多媒体

第十二章 启动与激活

第十三章 文件和数据

在应用程序的开发过程中，数据的读写操作是一项基本、必备的操作。需要熟练掌握相关的技术。

13.1 文件与目录

UWP 提供了对文件/目录操作的支持，使用 UWP 提供的 API，可以实现最常见的文件读写操作。文件读写相关的主要类型，主要分布在 **Windows.Storage** 命名空间及该命名空间的子命名空间中。

表 13.1: 文件/目录操作相关的重要类型

类型名	说明
StorageFile	表示一个文件实例。
StorageFolder	表示一个目录。
KnownFolders	静态类型，可访问几个特殊的目录。
FileIO	针对 StorageFile 实例而设计，通过一系列静态方法来实现对文件的读写。
PathIO	针对表示文件（夹）的字符串而设计，通过一系列静态方法来实现对文件的读写。

13.2 XML 数据处理

13.2.1 XML 格式简介

13.2.2 读写 XML

Windows.Data.Xml.Dom 命名空间下提供了若干类型，可以帮助开发者对 XML 文档进行读取、写入、筛选等操作。其中 **XmlDocument** 类是比较核心的类型，它表示一个 XML 文档的实例，使用该类可以通过代码来构建 XML 文档。

在读取 XML 数据时，可以调用 **LoadFromUriAsync**（从 URI 加载）方法或 **LoadFromFileAsync**（从文件加载）两个静态成员，直接返回 **XmlDocument** 对象实例，随后，就可以对 XML 文档进行读取或编辑操作。如果要创建全新的 XML 文档，可在实例化 **XmlDocument** 类后，调用相应的方法来为文档创建各种类型的节点：

- **CreateComment** 方法：创建 XML 注释节点，返回类型为 **XmlComment**；

- **CreateElement** 方法: 创建 XML 元素, 返回类型为 **XmlElement**;
- **CreateTextNode** 方法: 创建纯文本节点;
- **CreateAttribute** 方法: 创建 XML 元素属性的 “name = value” 对, 返回类型为 **XmlAttribute**;
- **CreateCDataSection** 方法: 创建 CData 节点, 可以存储不被 XML 解析器分析的文本;

不管是 **XmlDocument**, 还是 **XmlComment**、**XmlElement** 等类型的节点, 它们都实现了同一个接口 **IXmlNode**, 所以只需要调用 **A** 节点的 **AppendChild** 方法, 并将 **B** 节点作为参数, 就可以将 **B** 节点添加到 **A** 节点的子节点集合中。要从 **A** 节点的子节点集合中删除 **B** 节点, 调用 **RemoveChild** 方法即可。

下面通过一个实例来展示如何创建一个 XML 文档和读取 XML 文档。

XmlSample 页面的 XAML 代码如下:

```

1 <Grid Background="{ThemeResource ApplicationPageBackgroundThemeBrush}">
2     <Grid.RowDefinitions>
3         <RowDefinition Height="*" />
4         <RowDefinition Height="auto" />
5     </Grid.RowDefinitions>
6
7     <CommandBar Grid.Row="1">
8         <AppBarButton x:Name="SaveXml" Icon="Save" Label="创建" Click="SaveXml_Click"/>
9         <AppBarButton x:Name="LoadXml" Icon="Read" Label="读取" Click="LoadXml_Click"/>
10    </CommandBar>
11
12    <TextBlock Name="XmlTextBlock" TextWrapping="Wrap" Margin="5"/>
13 </Grid>

```

可用下面的代码创建并保存 XML 文档 (函数 **SaveXml_Click**):

```

1 private async void SaveXml_Click(System.Object sender, RoutedEventArgs e)
2 {
3     //创建 XmlDocument 实例
4     XmlDocument doc = new XmlDocument();
5     XmlElement root = doc.CreateElement("Books");
6     doc.AppendChild(root);
7
8     XmlElement book = doc.CreateElement("book");
9     // 设置属性
10    book.SetAttribute("ISBN", "978-0321563842");
11    book.SetAttribute("Version", "4th Edition");
12    XmlText text = doc.CreateTextNode("The C++ Programming Language");
13    book.AppendChild(text);
14
15    root.AppendChild(book);
16    // 保持到文件
17    StorageFolder local = ApplicationData.Current.LocalFolder;
18    StorageFile xmlFile = await local.CreateFileAsync("sample.xml", CreationCollisionOption.
19        ReplaceExisting);
20    if (xmlFile != null)
21    {
22        await doc.SaveToFileAsync(xmlFile);
23        await new MessageDialog("File Saved!").ShowAsync();
24    }
25 }

```



```
23     }
24 }
```

可用下面的代码读取 XML 文档（函数 *LoadXml_Click*）:

```
1 private async void LoadXml_Click(System.Object sender, RoutedEventArgs e)
2 {
3     // 从本地文件中加载XML
4     StorageFolder local = ApplicationData.Current.LocalFolder;
5     StorageFile xmlFile = await local.GetFilesAsync("sample.xml");
6     if (xmlFile != null)
7     {
8         XmlDocument doc = await XmlDocument.LoadFromFileAsync(xmlFile);
9         XmlTextBlock.Text = doc.GetXml();
10    }
11 }
```

13.2.3 相关类简介

13.3 JSON 数据处理

JSON (JavaScript Object Notation) 即 JavaScript 对象表示方法。可用简单的文本来描述 JavaScript 语言所能识别的对象。

Windows.Data.Json 命名空间下包含一些让开发者能够轻松访问和处理 JSON 格式数据的类型。

- *IJsonValue* 接口: 对封装 JSON 值的类型进行界定规范。其中 *Stringify* 方法可以返回某个 JSON 值的字符串表示形式;
- *JsonValue* 类: 表示一个简单的 JSON 值, 如字符串、数值等。
- *JsonArray* 类: 表示 JSON 中的数值;
- *JsonObject* 类: 表示一个单独的 JSON 对象。

下面通过一个实例来展示如何创建一个 JSON 文档和读取 JSON 文档。

JsonSample 页面的 XAML 代码如下:

```
1 <Grid Background="{ThemeResource ApplicationPageBackgroundThemeBrush}">
2     <Grid.RowDefinitions>
3         <RowDefinition Height="*" />
4         <RowDefinition Height="*" />
5         <RowDefinition Height="auto" />
6     </Grid.RowDefinitions>
7
8     <CommandBar Grid.Row="2">
9         <AppBarButton x:Name="SaveJson" Icon="Save" Label="创建" Click="SaveJson_Click"/>
10        <AppBarButton x:Name="LoadJson" Icon="Read" Label="读取" Click="LoadJson_Click"/>
11    </CommandBar>
12
13    <TextBlock Name="SaveJsonTextBlock" Grid.Row="0" TextWrapping="Wrap" Margin="5"/>
```

```
14 <TextBlock Name="LoadJsonTextBlock" Grid.Row="1" TextWrapping="Wrap" Margin="5"/>
15 </Grid>
```

可用下面的代码创建并保存 JSON（函数 *SaveJson_Click*）

```
1 private async void SaveJson_Click(object sender, RoutedEventArgs e)
2 {
3     JsonObject obj = new JsonObject();
4     obj["Title"] = JsonValue.CreateStringValue("The C++ Programming Language");
5     obj["ISBN"] = JsonValue.CreateStringValue("978-0321563842");
6     obj["Version"] = JsonValue.CreateStringValue("4th Edition");
7
8     SaveJsonTextBlock.Text = obj.Stringify();
9
10    var local = ApplicationData.Current.LocalFolder;
11    var jsonFile = await local.CreateFileAsync("sample.json", CreationCollisionOption.
        ReplaceExisting);
12    if (jsonFile != null)
13    {
14        await FileIO.WriteTextAsync(jsonFile, obj.Stringify());
15        await new MessageDialog("File Saved!").ShowAsync();
16    }
17 }
```

可用下面的代码读取 JSON 文档（函数 *LoadJson_Click*）：

```
1 private async void LoadJson_Click(object sender, RoutedEventArgs e)
2 {
3     var local = ApplicationData.Current.LocalFolder;
4     var jsonFile = await local.GetFileAsync("sample.json");
5     if (jsonFile != null)
6     {
7         LoadJsonTextBlock.Text = await FileIO.ReadTextAsync(jsonFile);
8     }
9 }
```

第十四章 应用设置和数据

应用设置是指 Windows Universal Platform 应用中可由用户自定义的部分，比如应用的颜色等。

应用数据是应用自身创建和管理的数据，主要包含运行时的状态、应用设置、参考内容以及其他设置等。

第十五章 数据库编程

15.1 SQLite 数据库的使用

<https://blogs.windows.com/buildingapps/2017/02/06/using-sqlite-databases-uwp-apps/>

For many developers, SQLite has become the preferred client-side technology for data storage. It is a server-less, embedded, open-source database engine that satisfies most local data access scenarios. There are numerous advantages that come with its use, many of which are explained in the SQLite about page.

Since the Windows 10 Anniversary Update (Build 14393), SQLite has also shipped as part of the Windows SDK. This means that when you are building your Universal Windows Platform (UWP) app that runs across the different Windows device form factors, you can take advantage of the SDK version of SQLite for local data storage. This comes with some advantages:

- Your application size reduces since you don't download your own SQLite binary and package it as part of your application
 - Note: *Microsoft.Data.SQLite* (used in the example below) currently has an issue where both SQLite3.dll and WinSQLite.dll are loaded in memory whenever a .NET Native version of your application is run. This is a tracked issue that will be addressed in subsequent updates of the library.
- You can depend on the Windows team to update the version of SQLite running on the operating system with every release of Windows.
- Application load time has the potential to be faster since the SDK version of SQLite will likely already be loaded in memory.

Below, we provided a quick coding example on how to consume the SDK version of SQLite in your C# application.

Note: Since the Windows SDK version of SQLite has only been available since the Windows 10 Anniversary Update, it can only be used for UWP apps targeting Build 14393 or higher.

15.1.1 C# Example

In this example, we will build a UWP application that will allow users to input text into an app local database. The goal is to provide developers with concise guidance on how to use the SQLite



图 15.1

binary that's shipped as part of the Windows SDK. Therefore this code sample is meant to be as simple as possible, so as to provide a foundation that can be further built upon.

An example of the end product is shown below:

15.1.2 SQLite C# API Wrappers

As mentioned in the SQLite documentation, the API provided by SQLite is fairly low-level and can add an additional level of complexity for the developer. Because of this, many open-source libraries have been produced to act as wrappers around the core SQLite API. These libraries abstract away a lot of the core details behind SQLite, allowing developers to more directly deal with executing SQL statements and parsing the results. For SQLite consumption across Windows, we recommend the open-source Microsoft.Data.Sqlite library built by the ASP.NET team. It is actively being maintained and provides an intuitive wrapper around the SQLite API. The rest of the example assumes use of the Microsoft.Data.Sqlite library.

Alternative SQLite wrappers are also linked in the “Additional Resources” section below.

15.1.3 Visual Studio set-up

The packages used in this sample have a dependency on NuGet version 3.5 or greater. You can check your version of NuGet by going to Help About Microsoft Visual Studio and looking through the




图 15.2

Installed Products for NuGet Package Manager. You can go to the NuGet download page and grab the version 3.5 VSIX update if you have a lower version.

Note: Visual Studio 2015 Update 3 is pre-installed with NuGet version 3.4, and will likely require an upgrade. Visual Studio 2017 RC is installed with NuGet version 4.0, which works fine for this sample.

15.1.3.1 Adding *Microsoft.Data.Sqlite* and upgrading the .NET Core template

The *Microsoft.Data.Sqlite* package relies on at least the 5.2.2 version of .NET Core for UWP, so we'll begin by upgrading this:

- Right click on *References* → *Manage NuGet Packages*
- Under the *Installed* tab, look for the *Microsoft.NETCore.UniversalWindowsPlatform* package and check the version number on the right-hand side. If it's not up to date, you'll be able to update to version 5.2.2 or higher.

Note: Version 5.2.2 is the default for VS 2017 RC. Therefore, this step is not required if you are using this newest version of Visual Studio.


To add the *Microsoft.Data.Sqlite* NuGet package to your application, follow a similar pattern:

- Right-click on *References* → *Manage NuGet Packages*
- Under the Browse tab, search for the *Microsoft.Data.Sqlite* package and install it.

15.1.4 Code

15.1.4.1 Application User Interface

We'll start off by making a simple UI for our application so we can see how to add and retrieve entries from our SQLite database.

图 15.3: *Microsoft.Data.Sqlite* 安装界面

```

1 <Grid Background="{ThemeResource ApplicationPageBackgroundThemeBrush}">
2     <StackPanel>
3         <TextBox Name="Input_Box"></TextBox>
4         <Button Click="Add_Text">Add</Button>
5         <ListView Name="Output">
6             <ListView.ItemTemplate>
7                 <DataTemplate>
8                     <TextBlock Text="{Binding}" />
9                 </DataTemplate>
10            </ListView.ItemTemplate>
11        </ListView>
12    </StackPanel>
13</Grid>

```

There are three important parts to our application's interface:

1. A text box that allows us to take text from the user.
2. A button linked to an event for pulling the text and placing it in the SQLite database.
3. An ItemTemplate to show previous entries in the database.

15.1.4.2 Code Behind for Application

In the App.xaml.cs and MainPage.xaml.cs files generated by Visual Studio, we'll start by importing the Microsoft.Data.Sqlite namespaces that we'll be using.

```

1 using Microsoft.Data.Sqlite;
2 using Microsoft.Data.Sqlite.Internal;

```

Then as part of the app constructor, we'll run a "CREATE TABLE IF NOT EXISTS" command to guarantee that the SQLite .db file and table are created the first time the application is launched.

```

1 public App()
2 {
3     this.InitializeComponent();
4     this.Suspending += OnSuspending;
5     SqliteEngine.UseWinSqlite3(); //Configuring library to use SDK version of SQLite
6     using (SqliteConnection db = new SqliteConnection("Filename=sqliteSample.db"))

```



```

7      {
8          db.Open();
9          String tableCommand = @"CREATE TABLE IF NOT EXISTS MyTable (
10                                     Primary_Key INTEGER PRIMARY KEY AUTOINCREMENT,
11                                     Text_Entry NVARCHAR(2048) NULL)";
12          SqliteCommand createTable = new SqliteCommand(tableCommand, db);
13          try
14          {
15              createTable.ExecuteReader();
16          }
17          catch (SqliteException e)
18          {
19              //Do nothing
20          }
21      }
22  }

```

There are couple of points worth noting with this code:

1. We make a call to `SqliteEngine.UseWinSqlite3()` before making any other SQL calls, which guarantees that the `Microsoft.Data.Sqlite` framework will use the SDK version of SQLite as opposed to a local version.
2. We then open a connection to a SQLite .db file. The name of the file passed as a String is your choice, but should be consistent across all `SqliteConnection` objects. This file is created on the fly the first time it's called, and is stored in the application's local data store.
3. After establishing the connection to the database, we instantiate a `SqliteCommand` object passing in a String representing the specific command and the `SqliteConnection` instance, and call `execute`.
4. We place the `ExecuteReader()` call inside a try-catch block. This is because SQLite will always throw a `SqliteException` whenever it can't execute the SQL command. Not getting the error confirms that the command went through correctly.

Next, we'll add code in the View's code-behind file to handle the button-clicked event. This will take text from the text box and put it into our SQLite database.

```

1  private void Add_Text(object sender, RoutedEventArgs e)
2  {
3      using (SqliteConnection db = new SqliteConnection("Filename=sqliteSample.db"))
4      {
5          db.Open();
6
7          SqliteCommand insertCommand = new SqliteCommand();
8          insertCommand.Connection = db;
9
10         //Use parameterized query to prevent SQL injection attacks
11         insertCommand.CommandText = "INSERT INTO MyTable VALUES (NULL, @Entry)";
12         insertCommand.Parameters.AddWithValue("@Entry", Input_Box.Text);
13
14         try
15         {

```

```

16         insertCommand.ExecuteReader();
17     }
18     catch (SQLiteException error)
19     {
20         //Handle error
21         return;
22     }
23     db.Close();
24 }
25 Output.ItemsSource = Grab_Entries();
26 }

```

As you can see, this isn't drastically different than the SQLite code explained in the app's constructor above. The only major deviation is the use of parameters in the query so as to prevent SQL injection attacks. You will find that commands that make changes to the database (i.e. creating tables, or inserting entries) will mostly follow the same logic.

Finally, we go to the implementation of the `Grab_Entries()` method, where we grab all the entries from the `Text_Entry` column and fill in the XAML template with this information.

```

1 private List<String> Grab_Entries()
2 {
3     List<String> entries = new List<string>();
4     using (SQLiteConnection db = new SQLiteConnection("Filename=sqliteSample.db"))
5     {
6         db.Open();
7         SQLiteCommand selectCommand = new SQLiteCommand("SELECT Text_Entry from MyTable", db);
8         SQLiteDataReader query;
9
10        try
11        {
12            query = selectCommand.ExecuteReader();
13        }
14        catch (SQLiteException error)
15        {
16            //Handle error
17            return entries;
18        }
19
20        while(query.Read())
21        {
22            entries.Add(query.GetString(0));
23        }
24        db.Close();
25    }
26    return entries;
27 }

```

Here, we take advantage of the `SQLiteDataReader` object returned from the `ExecuteReader()` method to run through the results and add them to the `List` we eventually return. There are two methods worth pointing out:

1. The `Read()` method advances through the rows returned back from the executed SQLite command,

and returns a boolean based on whether you’ ve reached the end of the query or not (True if there are more rows left, and False if you’ ve reached the end).

2. The `GetString()` method returns the value of the specified column as a `String`. It takes in one parameter, an `int` that represents the zero-based column ordinal. There are similar methods like `GetDateTime()` and `GetBoolean()` that you can use based on the data type of the column that you are dealing with.
 - (a) The ordinal parameter isn’ t as relevant in this example since we are selecting all the entries in a single column. However, in the case where multiple columns are part of the query, the ordinal represents the column you are pulling from. So if we selected both `Primary_Key` and `Text_Entry`, then `GetString(0)` would return the value of `Primary_Key` `String` and `GetString(1)` would return the value of `Text_Entry` as a `String`.

And that’ s it! You can now build your application and add any text you like into your SQLite database. You can even close and open your application to see that the data persists.

A link to the full code can be found at: <https://github.com/Microsoft/windows-developer-blog-samples/tree/master/Samples/SQLiteSample>

15.1.4.3 Moving Forward

There are plenty of additions that you can make to tailor this sample to your needs:

1. Adding more tables and more complicated queries.
2. Providing more sanitation over the text entries to prevent faulty user input.
3. Communicating with your database in the cloud to propagate information across devices.
4. And so much more!

15.1.5 What about Entity Framework?

For those developers looking to abstract away particular database details, Microsoft’ s Entity Framework provides a great model that lets you work at the “Object” layer as opposed to the database access layer. You can create models for your database using code, or visually define your model in the EF designer. Then Entity Framework makes it super-easy to generate a database from your defined object model. It’ s also possible to map your models to existing databases you may have already created.

SQLite is one of many database back-ends that Entity Framework is configured to work with. This documentation provides an example to work from.

15.1.6 Conclusion

From embedded applications for Windows 10 IoT Core to a cache for enterprise relations database server (RDBS) data, SQLite is the premier choice for any application that needs local storage support. SQLite' s server-less and self-contained architecture makes it compact and easy to manage, while its tried and tested API surface coupled with its massive community support provides additional ease of use. And since it ships as part of Windows 10, you can have peace of mind, knowing that you' re always using an up-to-date version of the binary.

As always, please leave any questions in the comments section, and we' ll try our best to answer them. Additional resources are also linked below.

第十六章 网络通信

第十七章 传感器与地理信息

第十八章 语言识别技术

附录

18.1 元素周期表

表	期	周	素	元
---	---	---	---	---

1

2.20

1s

H 氢

Hydrogen

1.00784 - 1.00811

3

0.98

2s

Li 锂

Lithium

6.938 - 6.907

4

1.57

2s

Be 铍

Beryllium

9.01238(10)

11

0.93

3s

Na 钠

Sodium

22.98976928(2)

12

1.31

3s

Mg 镁

Magnesium

24.304 - 24.307

19

0.82

4s

Ca 钙

Calcium

40.078(1)

37

0.82

5s

Sr 锶

Strontium

87.62(1)

55

0.79

6s

Ba 钡

Barium

137.327(7)

87

0.7

7s

Ra 镭

Radium

226

2

He 氦

Helium

4.002603(2)

3

0.98

2p

Li 锂

Lithium

6.938 - 6.907

4

1.57

2p

Be 铍

Beryllium

9.01238(10)

11

0.93

3s

Na 钠

Sodium

22.98976928(2)

12

1.31

3s

Mg 镁

Magnesium

24.304 - 24.307

19

0.82

4s

Ca 钙

Calcium

40.078(1)

37

0.82

5s

Sr 锶

Strontium

87.62(1)

55

0.79

6s

Ba 钡

Barium

137.327(7)

87

0.7

7s

Ra 镭

Radium

226

5

2.04

2p

B 硼

Boron

10.806 - 10.821

6

2.55

2p

C 碳

Carbon

12.0096 - 12.0116

13

1.61

3p

Al 铝

Aluminium

26.9815385(7)

14

1.90

3p

Si 硅

Silicon

28.085 - 28.086

21

1.36

3d

Sc 钪

Scandium

44.955908(5)

22

1.54

3d

Ti 钛

Titanium

47.867(1)

39

1.22

4d

Y 钇

Yttrium

88.90584(2)

57

71

镧系

Lanthanides

57-71

63

0.89

6s

La 镧

Lanthanum

138.90547(86)(6)

72

1.3

5d

Hf 铪

Hafnium

178.49(2)

104

6d

Rf 𨭻

Rutherfordium

(261)

89

103

铜系

Actinides

89-103

105

6d

Db 𨭻

Dubnium

(268)

106

6d

Sg 𨭻

Seaborgium

(269)

107

6d

Bh 𨭻

Bohrium

(270)

108

6d

Hs 𨭻

Hassium

(269)

109

6d

Mt 𨭻

Mtnerium

(275)

110

6d

Ds 𨭻

Darmstadtium

(281)

111

6d

Rg 𨭻

Roentgenium

(282)

112

6d

Cn 𨭻

Copernicium

(285)

113

7p

Nh 𨭻

Nihonium

(286)

114

7p

Fl 𨭻

Flerovium

(289)

115

7p

Mc 𨭻

Moscovium

(289)

116

7p

Lv 𨭻

Livermorium

(293)

117

7p

Ts 𨭻

Tennessine

(294)

118

7p

Og 𨭻

Oganesson

(294)

13

1.61

3p

Al 铝

Aluminium

26.9815385(7)

14

1.90

3p

Si 硅

Silicon

28.085 - 28.086

21

1.36

3d

Sc 钪

Scandium

44.955908(5)

22

1.54

3d

Ti 钛

Titanium

47.867(1)

39

1.22

4d

Y 钇

Yttrium

88.90584(2)

57

71

镧系

Lanthanides

57-71

63

0.89

6s

La 镧

Lanthanum

138.90547(86)(6)

72

1.3

5d

Hf 铪

Hafnium

178.49(2)

104

6d

Rf 𨭻

Rutherfordium

(261)

89

103

铜系

Actinides

89-103

105

6d

Db 𨭻

Dubnium

(268)

106

6d

Sg 𨭻

Seaborgium

(269)

107

6d

Bh 𨭻

Bohrium

(270)

108

6d

Hs 𨭻

Hassium

(269)

109

6d

Mt 𨭻

Mtnerium

(275)

110

6d

Ds 𨭻

Darmstadtium

(281)

111

6d

Rg 𨭻

Roentgenium

(282)

112

6d

Cn 𨭻

Copernicium

(285)

113

7p

Nh 𨭻

Nihonium

(286)

114

7p

Fl 𨭻

Flerovium

(289)

115

7p

Mc 𨭻

Moscovium

(289)

116

7p

Lv 𨭻

Livermorium

(293)

117

7p

Ts 𨭻

Tennessine

(294)

118

7p

Og 𨭻

Oganesson

(294)

15

2.04

2p

B 硼

Boron

10.806 - 10.821

16

2.55

2p

C 碳

Carbon

12.0096 - 12.0116

13

1.61

3p

Al 铝

Aluminium

26.9815385(7)

14

1.90

3p

Si 硅

Silicon

28.085 - 28.086

21

1.36

3d

Sc 钪

Scandium

44.955908(5)

22

1.54

3d

Ti 钛

Titanium

47.867(1)

39

1.22

4d

Y 钇

Yttrium

88.90584(2)

57

71

镧系

Lanthanides

57-71

63

0.89

6s

La 镧

Lanthanum

138.90547(86)(6)

72

1.3

5d

Hf 铪

Hafnium

178.49(2)

104

6d

Rf 𨭻

Rutherfordium

(261)

89

103

铜系

Actinides

89-103

105

6d

Db 𨭻

Dubnium

(268)

106

6d

Sg 𨭻

Seaborgium

(269)

107

6d

Bh 𨭻

Bohrium

(270)

108

6d

Hs 𨭻

Hassium

(269)

109

6d

Mt 𨭻

Mtnerium

(275)

110

6d

Ds 𨭻

Darmstadtium

(281)

111

6d

Rg 𨭻

Roentgenium

(282)

112

6d

Cn 𨭻

Copernicium

(285)

113

7p

Nh 𨭻

Nihonium

(286)

114

7p

Fl 𨭻

Flerovium

(289)

115

7p

Mc 𨭻

Moscovium

(289)

116

7p

Lv 𨭻

Livermorium

(293)

117

7p

Ts 𨭻

Tennessine

(294)

118

7p

Og 𨭻

Oganesson

(294)

17

3.44

2p

O 氧

Oxygen

15.99906 - 15.99977

18

3.16

2p

F 氟

Fluorine

18.998403163(6)

25

2.04

2p

B 硼

Boron

10.806 - 10.821

26

2.55

2p

C 碳

Carbon

12.0096 - 12.0116

13

1.61

3p

Al 铝

Aluminium

26.9815385(7)

14

1.90

3p

Si 硅

Silicon

28.085 - 28.086

21

1.36

3d

Sc 钪

Scandium

44.955908(5)

22

1.54

3d

Ti 钛

Titanium

47.867(1)

39

1.22

4d

Y 钇

Yttrium

88.90584(2)

57

71

镧系

Lanthanides

57-71

63

0.89

6s

La 镧

Lanthanum

138.90547(86)(6)

72

1.3

5d

Hf 铪

Hafnium

178.49(2)

104

6d

Rf 𨭻

Rutherfordium

(261)

89

103

铜系

Actinides

89-103

105

6d

Db 𨭻

Dubnium

(268)

106

6d

Sg 𨭻

Seaborgium

(269)

107

6d

Bh 𨭻

Bohrium

(270)

108

6d

Hs 𨭻

Hassium

(269)

109

6d

Mt 𨭻

Mtnerium

(275)

110

6d

Ds 𨭻

Darmstadtium

(281)

111

6d

Rg 𨭻

Roentgenium

(282)

112

6d

Cn 𨭻

Copernicium

(285)

113

7p

Nh 𨭻

Nihonium

(286)

114

7p

Fl 𨭻

Flerovium

(289)

115

7p

Mc 𨭻

Moscovium

(289)

116

7p

Lv 𨭻

Livermorium

(293)

117

7p

Ts 𨭻

Tennessine

(294)

118

7p

Og 𨭻

Oganesson

(294)

27

3.98

2p

Cl 氯

Chlorine

35.446 - 35.457

28

3.16

2p

Ar 氩

Argon

39.948(1)

35

2.04

2p

B 硼

Boron

10.806 - 10.821

36

2.55

2p

C 碳

Carbon

12.0096 - 12.0116

13

1.61

3p

Al 铝

Aluminium

26.9815385(7)

14

1.90

3p

Si 硅

Silicon

28.085 - 28.086

21

1.36

3d

Sc 钪

Scandium

44.955908(5)

22

1.54

3d

Ti 钛

Titanium

47.867(1)

39

1.22

4d

Y 钇

Yttrium

88.90584(2)

57

71

镧系

Lanthanides

57-71

63

0.89

6s

La 镧

Lanthanum

138.90547(86)(6)

72

1.3

5d

Hf 铪

Hafnium

178.49(2)

104

6d

Rf 𨭻

Rutherfordium

(261)

89

103

铜系

Actinides

89-103

105

6d

Db 𨭻

Dubnium

(268)

106

6d

Sg 𨭻

Seaborgium

(269)

107

6d

Bh 𨭻

Bohrium

(270)

108

6d

Hs 𨭻

Hassium

(269)

109

6d

Mt 𨭻

Mtnerium

(275)

110

6d

Ds 𨭻

Darmstadtium

(281)

111

6d

Rg 𨭻

Roentgenium

(282)

112

6d

Cn 𨭻

Copernicium

(285)

113

7p

Nh 𨭻

Nihonium

(286)

114

7p

Fl 𨭻

Flerovium

(289)

115

7p

Mc 𨭻

Moscovium

(289)

116

7p

Lv 𨭻

Livermorium

(293)

117

7p

Ts 𨭻

Tennessine

(294)

118

7p

Og 𨭻

Oganesson

(294)

31

3.04

2p

N 氮

Nitrogen

14.00643 - 14.00728

32

3.16

2p

O 氧

Oxygen

15.99906 - 15.99977

33

3.44

2p

F 氟

Fluorine

18.998403163(6)

35

2.04

2p

B 硼

Boron

10.806 - 10.821

36

2.55

2p

C 碳

Carbon

12.0096 - 12.0116

13

1.61

3p

Al 铝

Aluminium

26.9815385(7)

14

1.90

3p

Si 硅

Silicon

28.085 - 28.086

21

1.36

3d

Sc 钪

Scandium

44.955908(5)

22

1.54

3d

Ti 钛

Titanium

47.867(1)

39

1.22

4d

Y 钇

Yttrium

88.90584(2)

57

71

镧系

Lanthanides

57-71

63

0.89

6s

La 镧

Lanthanum

138.90547(86)(6)

72

1.3

5d

Hf 铪

Hafnium

178.49(2)

104

6d

Rf 𨭻

Rutherfordium

(261)

89

103

铜系

Actinides

89-103

105

6d

Db 𨭻

Dubnium

(268)

106

6d

Sg 𨭻

Seaborgium

(269)

107

6d

Bh 𨭻

Bohrium

(270)

108

6d

Hs 𨭻

Hassium

(269)

109

6d

Mt 𨭻

Mtnerium

(275)

110

6d

Ds 𨭻

Darmstadtium

(281)

111

6d

Rg 𨭻

Roentgenium

(282)

112

6d

Cn 𨭻

Copernicium

(285)

113

7p

Nh 𨭻

Nihonium

(286)

114

7p

Fl 𨭻

Flerovium

(289)

115

7p

Mc 𨭻

Moscovium

(289)

116

7p

Lv 𨭻

Livermorium

(293)

117

7p

Ts 𨭻

Tennessine

(294)

118

7p

Og 𨭻

Oganesson

(294)

37

3.04

2p

N 氮

Nitrogen

14.00643 - 14.00728

38

3.16

2p

O 氧

Oxygen

15.99906 - 15.99977

39

3.44

2p

F 氟

Fluorine

18.998403163(6)

41

2.04

2p

B 硼

Boron

10.806 - 10.821

42

2.55

2p

C 碳

Carbon

12.0096 - 12.0116

13

1.61

3p

Al 铝

Aluminium

26.9815385(7)

14

1.90

3p

Si 硅

Silicon

28.085 - 28.086

21

1.36

3d

Sc 钪

Scandium

44.955908(5)

22

1.54

3d

Ti 钛

Titanium

47.867(1)

39

1.22

4d

Y 钇

Yttrium

88.90584(2)

57

71

镧系

Lanthanides

57-71

63

0.89

6s

La 镧

Lanthanum

138.90547(86)(6)

72

1.3

5d

Hf 铪

Hafnium

178.49(2)

104

6d

Rf 𨭻

Rutherfordium

(261)

89

103

铜系

Actinides

89-103

105

6d

Db 𨭻

Dubnium

(268)

106

6d

Sg 𨭻

Seaborgium

(269)

107

6d

Bh 𨭻

Bohrium

(270)

108

6d

Hs 𨭻

Hassium

(269)

109

6d

Mt 𨭻

Mtnerium

(275)

110

6d

Ds 𨭻

Darmstadtium

(281)

111

6d

Rg 𨭻

Roentgenium

(282)

112

6d

Cn 𨭻

Copernicium

(285)

113

7p

Nh 𨭻

Nihonium

(286)

114

7p

Fl 𨭻

Flerovium

(289)

115

7p

Mc 𨭻

Moscovium

(289)

116

7p

Lv 𨭻

Livermorium

(293)

117

7p

Ts 𨭻

Tennessine

(294)

118

7p

Og 𨭻

Oganesson

(294)

43

3.04

2p

N 氮

Nitrogen

14.00643 - 14.00728

44

3.16

2p

O 氧

Oxygen

15.99906 - 15.99977

45

3.44

2p

F 氟

Fluorine

18.998403163(6)

47

2.04

2p

B 硼

Boron

10.806 - 10.821

48

2.55

2p

C 碳

Carbon

12.0096 - 12.0116

13

1.61

3p

Al 铝

Aluminium

26.9815385(7)

14

1.90

3p

Si 硅

Silicon

28.085 - 28.086

21

1.36

3d

Sc 钪

Scandium

44.955908(5)

22

1.54

3d

Ti 钛

Titanium

47.867(1)

39

1.22

4d

Y 钇

Yttrium

88.90584(2)

57

71

镧系

Lanthanides

57-71

63

0.89

6s

La 镧

Lanthanum

138.90547(86)(6)

72

1.3

5d

Hf 铪

Hafnium

178.49(2)

104

6d

Rf 𨭻

Rutherfordium

(261)

89

103

铜系

Actinides

89-103

105

6d

Db 𨭻

Dubnium

(268)

106

6d

Sg 𨭻

Seaborgium

(269)

107

6d

Bh 𨭻

Bohrium

(270)

108

6d

Hs 𨭻

Hassium

(269)

109

6d

Mt 𨭻

Mtnerium

(275)

110

6d

Ds 𨭻

Darmstadtium

(281)

111

6d

Rg 𨭻

Roentgenium

(282)

112

6d

Cn 𨭻

Copernicium

(285)

113

7p

Nh 𨭻

Nihonium

(286)

114

7p

Fl 𨭻

Flerovium

(289)

115

7p

Mc 𨭻

Moscovium

(289)

116

7p

Lv 𨭻

Livermorium

(293)

117

7p

Ts 𨭻

Tennessine

(294)

118

7p

Og 𨭻

Oganesson

(294)

49

3.04

2p

N 氮

Nitrogen

14.00643 - 14.00728

50

3.16

2p

O 氧

Oxygen

15.99906 - 15.99977

51

3.44

2p

F 氟

Fluorine

18.998403163(6)

53

2.04

2p

B 硼

Boron

10.806 - 10.821

54

2.55

2p

C 碳

Carbon

12.0096 - 12.0116

13

1.61

3p

Al 铝

Aluminium

26.9815385(7)

14

1.90

3p

Si 硅

Silicon

28.085 - 28.086

21

1.36

3d

Sc 钪

Scandium

44.955908(5)

22

1.54

3d

Ti 钛

Titanium

47.867(1)

39

1.22

4d

Y 钇

Yttrium

88.90584(2)

57

71

镧系

Lanthanides

57-71

63

0.89

6s

La 镧

Lanthanum

138.90547(86)(6)

72

1.3

5d

Hf 铪

Hafnium

178.49(2)

104

6d

Rf 𨭻

Rutherfordium

(261)

89

103

铜系

Actinides

89-103

105

6d

Db 𨭻

Dubnium

(268)

106

6d

Sg 𨭻

Seaborgium

(269)

107

6d

Bh 𨭻

Bohrium

(270)

108

6d

Hs 𨭻

Hassium

(269)

109

6d

Mt 𨭻

Mtnerium

(275)

110

6d

Ds 𨭻

Darmstadtium

(281)

111

6d

Rg 𨭻

Roentgenium

(282)

112

6d

Cn 𨭻

Copernicium

(285)

113

7p</

Z = atomic number; eneg = electronegativity; ss = sub-shell; Sy = Symbol, Name = element name, saw = standard atomic weight

57	1.1	5d ³	La 镧	138.9047(7)	89	1.1	6d ²	Ac 锕	227
58	1.2	5d ²	Ce 铈	140.116(1)	90	1.3	5f ³	Th 钍	232
59	1.3	4f ³	Pr 镨	140.90766(2)	91	1.5	5f ²	Pa 镤	231.03588(2)
60	1.4	4f ²	Nd 钕	144.242(3)	92	1.38	5f ²	U 铀	238.02891(3)
61	1.3	4f ¹	Pm 钷	(143)	93	1.36	5f ¹	Np 镎	(237)
62	1.17	4f ⁰	Sm 钐	150.36(2)	94	1.28	5f ⁰	Pu 钷	(244)
63	1.2	4f ⁰	Eu 铕	151.964(1)	95	1.13	5f ⁰	Am 镅	(243)
64	1.2	4f ⁰	Gd 钆	157.25(3)	96	1.28	5f ⁰	Cm 锔	(247)
65	1.1	4f ⁰	Tb 铽	158.9253(2)	97	1.3	5f ⁰	Bk 锫	(247)
66	1.22	4f ⁰	Dy 镝	162.500(1)	98	1.3	5f ⁰	Cf 锎	(251)
67	1.23	4f ⁰	Ho 铥	164.93032(2)	99	1.3	5f ⁰	Es 镱	(252)
68	1.24	4f ⁰	Er 铒	167.259(3)	100	1.3	5f ⁰	Fm 镆	(257)
69	1.25	4f ⁰	Tm 铥	168.93422(2)	101	1.3	5f ⁰	Md 镆	(258)
70	1.1	4f ⁰	Yb 镱	173.045(10)	102	1.3	5f ⁰	No 镎	(259)
71	1.27	4f ⁰	Lu 镥	174.9668(1)	103	1.3	5f ⁰	Lr 镈	(260)

镍系

铜系

相对原子质量来源: (<http://ciaaw.org/atomic-weights.htm>). © 2017 张洋

An asterisk (*) next to a subshell indicates an anomalous (Aufbau rule-breaking) ground state electron configuration.

18.2 密码子表

密码子表